

1. 2 1/2 D. CHROME CAP W/BOLT
2. 2 1/4" DIA X 1 5/8" LEAD PLUG
3. 2 1/4" DIA X 3/8" LEAD SPACER
4. BUMPER
5. 1 1/2 OD X 1/16" STEEL WASHER
6. 2 1/4 OD X 3/8" RUBBER SPACER
7. 2 1/2 D. CHROME BOTTOM CAP (~ 7/8" HEX HOLE)
8. BUMPER DOUBLE SPRING LEAF ASS'Y
9. 1 1/4 OD X 1/8" FLAT WASHER
10. NUT

PROBABLY
HAVE TO REPLACE
THE STUDS.

IT SEEMS THESE
SHOULD BE 7/16-18
WITH A CASTLE NUT.

HOWEVER, ONE HAD A
"NEW" END WITH 1/4 THD/IN
WELDED ON AND THE OTHER
HAD "NEW" STUD WITH 16/IN.

FRONT RIGHT FRAME
PROTECTION WITH
RUBBER
BUSHING

CHROME
U-BOLT
3/8-20

STEEL SHELL

BRASS
HALF-BUSHING

← TYP ASS'Y
2 PLACES

3/8-20
CASTLE NUTS
2 REQ.

(HEX NUTS USED
ON THIS ASS'Y -
CASTLE NUTS
MISSING)

